mr.steamesteambaths Technical Specifications

Optional AutoFlush


Box Contents

- AutoFlush Valve with Cord
- Installation instructions

Operation

The optional AutoFlush System feature automatically drains the Mr.Steam® system following each use. A time delay allows the water to cool down (about two hours) before it drains by gravity for a safe and gentle operation.

NOTE: If the Express Steam option has been installed, the AutoFlush will drain for ten minutes then refill with fresh water to begin the pre-heat cycle.



Our exclusive AutoFlush automatically and electronically drains the system, providing CleanSteam... Every Time and introduces fresh water.

IMPORTANT: See Mr.Steam Installation, Operation and Maintenance Manual, PUR 101289, for details.

Click here to download this manual:

http://www.mrsteam.com/products/technical-downloads.html